

PS01509

LoRaWAN Class A/C AT Command Specification

V4.2

Document information

Info	Content
Keywords	<i>LoRaWAN, AT Command, UART, USB</i>
Abstract	This document defines AT command format used by Ai-Thinker LoRaWAN module

WARNING:

**This document is only for RHF76-052AM / RHF76-052CM modules
version higher than 2.1.0,
other version please refer to PS01509-V2.4 or PS01509-V3.1**

Content

Content.....	2
Tables.....	6
1 Introduction.....	1
1.1 Feature.....	1
1.2 Compare V2.1.x with V2.0.10.....	2
1.2.1 New.....	2
1.2.2 Not Compatible Command.....	2
1.2.3 Fixed Issue.....	3
1.3 Related Products.....	3
2 Preface.....	4
2.1 Conventions.....	4
2.2 Symbols.....	4
2.3 Format.....	4
2.3.1 Query.....	4
2.3.2 Configure / Control.....	4
2.3.3 Return.....	4
2.4 Error.....	5
2.5 EEPROM.....	5
3 Band Plans.....	6
3.1 Data Rate Scheme.....	6
3.2 Payload Length Limitation.....	7
3.3 TX Output Power Encoding.....	7
3.4 Channels.....	8
3.4.1 Default Uplink Channels.....	8
3.4.2 Downlink RXWIN1 Channels.....	8
3.4.3 Downlink RXWIN2 Channel.....	9
3.4.4 Join Request Channels.....	9
3.5 Join Duty Cycle Limitation.....	10
3.6 RX1DROffset Limitation.....	10
3.6.1 EU868/EU434/CN470 /KR920/CN470PREQUEL/STE920.....	10
3.6.2 US915/ US915HYBRID/AU915.....	10
3.6.3 AS923.....	10

3.6.4 IN865.....	10
3.7 CFLIST.....	11
3.8 LinkAdrReq.....	11
3.9 Band Specific Limitation.....	11
3.9.1 US915/AU915/CN470 Channel Limitation.....	11
3.9.2 EU868 Duty Cycle Limitation.....	11
3.9.3 CN799 Duty Cycle Limitation.....	12
3.9.1 EU433 Duty Cycle Limitation.....	12
3.9.2 AS923 Dwell Time Limitation.....	12
3.9.3 KR920 Channels and TX Power Limitation.....	12
3.10 Frequency Range.....	12
3.10.1 AS923 Country Limitation.....	13
4 Commands.....	14
4.1 AT.....	15
4.2 VER.....	15
4.3 ID.....	15
4.4 RESET.....	16
4.5 MSG.....	16
4.5.1 LinkCheckReq.....	16
4.5.2 Error Status.....	17
4.6 CMSG.....	17
4.7 MSGHEX.....	18
4.8 CMSGHEX.....	18
4.9 PMSG.....	19
4.10 PMSGHEX.....	19
4.11 PORT.....	19
4.12 ADR.....	19
4.13 DR.....	19
4.13.1 Check and Set Data Rate.....	20
4.13.2 Data Rate Scheme.....	20
4.14 CH.....	20
4.14.1 Query Channel Configuration.....	20
4.14.2 Add or Delete Channel.....	21

4.14.3 Enable or Disable Channel.....	21
4.15 POWER.....	22
4.15.1 Set and Check Power.....	22
4.15.2 Force Set Power.....	22
4.15.3 Power Table.....	22
4.16 REPT.....	22
4.17 RETRY.....	22
4.18 RXWIN2.....	23
4.19 RXWIN1.....	23
4.20 KEY.....	23
4.21 FDEFAULT.....	25
4.22 DFU.....	25
4.23 MODE.....	26
4.24 JOIN.....	26
4.25 CLASS.....	27
4.25.1 Class C Downlink.....	27
4.26 DELAY.....	27
4.27 LW.....	28
4.27.1 CDR.....	28
4.27.2 ULDL.....	28
4.27.3 DC.....	29
4.27.4 NET.....	30
4.27.5 MC.....	30
4.27.6 THLD.....	30
4.27.7 BAT.....	31
4.27.8 TPS.....	31
4.27.9 SCR.....	31
4.27.10 JDC.....	31
4.27.11 LEN.....	32
4.28 WDT.....	32
4.29 LOWPOWER.....	32
4.29.1 Low Power Auto Mode.....	33
4.30 VDD.....	34

4.31 RTC.....	34
4.32 EEPROM.....	34
4.33 UART.....	34
4.33.1 TIMEOUT.....	34
4.33.2 BR.....	35
4.34 TEST.....	36
4.34.1 Help Information.....	36
4.34.2 Enter TEST mode.....	36
4.34.3 Query RF configuration.....	36
4.34.4 Set RF Configuration.....	37
4.34.5 TX LoRa Packet.....	38
4.34.6 RX LoRa Packet.....	38
4.34.7 TX Continuous Wave.....	39
4.34.8 TX Continuous LoRa.....	39
4.34.9 RSSI.....	39
4.34.10 LWDL.....	39
Revision.....	40

Tables

Table 1-1 Related products list.....	3
Table 2-1 Error code list.....	5
Table 2-2 Memorized configuration.....	5
Table 3-1 Data Rate Scheme.....	6
Table 3-2 RF Modulation Bit Rate.....	6
Table 3-3 Data Rate and Payload Length Map.....	7
Table 3-4 TX Power Table.....	7
Table 3-5 Default MaxEIRP Value and MaxEIRP Index Map.....	8
Table 3-6 MaxEIRP Table.....	8
Table 3-7 Default Uplink Channels.....	8
Table 3-8 Default Downlink RXWIN1 Channels.....	9
Table 3-9 Default RXWIN2 Configuration.....	9
Table 3-10 Join Request Channels.....	9
Table 3-11 Join Duty Cycle.....	10
Table 3-12 RX1DROffset Range.....	10
Table 3-13 AS923 RX1DROffset Effective Table.....	10
Table 3-14 IN865 RX1DROffset Effective Table.....	10
Table 3-15 CFList Definition.....	11
Table 3-16 LinkAdrReq ChMaskCntl Definition.....	11
Table 3-17 ETSI EU868 Regulation.....	12
Table 3-18 CN470 Duty Cycle Limitation.....	12
Table 3-19 CN470 Duty Cycle Limitation.....	12
Table 3-20 AS923 Dwell Time Limitation.....	12
Table 3-21 KR920 Channel and TX power limitation.....	12
Table 4-1 Command List.....	14
Table 4-2 Factory default configuration.....	25
Table 4-3 LoRaWAN Delay Items.....	28
Table 4-4 Duty Cycle Control.....	29
Table 4-5 TEST mode sub-command list.....	36
Table 4-6 MAX output power of HF and LF band.....	37

1 Introduction

Ai-Thinker™ LoRaWAN™ modem is [LoRaWAN](#) compatible device, which supports flexible LoRaWAN communication. This document is intended to describe a command interface implementation of LoRaWAN Class A/C protocol. LoRaWAN protocol is available from LoRa Alliance, it is recommended to review LoRaWAN specification before using LoRaWAN modem.

1.1 Feature

- LoRaWAN R1.0.2 band plan:
 - EU868 US915 US915HYBRID CN779 EU433 AU915 AU915OLD CN470 AS923 KR920 IN865
- User defined band plan:
 - CN470PREQUEL STE920
- LoRaWAN Class A/C
- All LoRaWAN 1.0.2 Class A/C MAC command:
 - LinkCheckReq / LinkCheckAns
 - LinkADRReq / LinkADRAns
 - DutyCycleReq / DutyCycleAns
 - RXParamSetupReq / RXParamSetupAns
 - DevStatusReq / DevStatusAns
 - NewChannelReq / NewChannelAns
 - RXTimingSetupReq / RXTimingSetupAns
 - TxParamSetupReq / TxParamSetupAns
 - DChannelReq / DChannelAns
- LoRaWAN dynamic choose Port Zero / FOpts to send uplink MAC command
- Flexible RXWIN2 configuration interface
- Configurable RXWIN1 channel frequency
- Possibility to enable full-duplex LoRaWAN system
- Maximum configurable 96 channels
- Maximum 255 bytes RF frame
- User configuration nonvolatile
- Numerous test commands (LoRa P2P, Class C downlink, Continuous Wave etc.)
- Flexible hexadecimal string parser
- Ultra-low power (1.4uA@3.3V 1.9uA@3.3 watchdog on)¹, intelligent auto low power mode
- Case insensitive commands
- 256 bytes EEPROM to save user data
- RTC time and supply voltage measurement
- Power supply measurement

¹ UART interface modem only

1.2 Compare V2.1.x with V2.0.10

1.2.1 New

- Support maximum 96 channels instead of 72
- Support new band plan
 - LoRaWAN 1.0.2 standard
 - ◆ CN779 / EU433 / AU915 / CN470 / AS923 / KR920 / IN865
 - User defined band plan:
 - ◆ CN470PREQUEL / STE920
- Support new MAC commands
 - TxParamSetupReq / TxParamSetupAns
 - DiChannelReq / DiChannelAns
- AT+DR=band will reset all LoRaWAN band specific parameters (channels, datarate, rxwin1, rxwin2)
- Support Fpending event
- Support LinkCheckAns event
- Add AT+CH=NUM command
- Add AT+POWER=TABLE command to show current power table
- Add AT+POWER=pow, FORCE command to force using a fixed TX power
- Add AT+LW=TPS, to set DownlinkDwellTime, UplinkDwellTime, MaxEIRP for AS923 band plan
- Add AT+LW=SCR, command, this command can be used to bypass MAX_FCNT_GAP checking, if it is on MAX_FCNT_GAP will be bypass.
- Add AT+UART=BR, this command can be used to set new baud rate
- AT+WDT=ON/OFF to enable or disable watchdog, need reset to make it valid, default ON.
 - Sleep current with watchdog on is ~2uA

1.2.2 Not Compatible Command

- Remove AT+DR=CUSTOM and AT+DR=CUSTOM, DRx, ...,
 - CUSTOM band plan is no longer supported
- Remove AT+RXWIN1 ON/OFF control, AT+RXWIN1=ch,freq to overwrite default rxwin1 frequency
- Remove AT+HELP
- Remove AT+REG
- Remove AT+TEST=HELP
- Change AT+TEST=RSSI return message format
- AT+TEST=LWDL returns "+TEST: LWDL DONE" instead of "+TEST: LORAWAN DOWNLINK TX DONE"
- + Add AT+TEST=RFCFG options, CRC/IQ/NET option is configurable
- AT+DFU=ON no longer returns "Enter bootloader after reboot in 5s..."
- AT+MSG/CMSG/MSGHEX/CMSGHEX command no longer prints MACCMD
- AT+MSG/CMSG/MSGHEX/CMSGHEX no longer echo "+xxx: TX "xxxxx "
- AT+MSG/CMSG/MSGHEX/CMSGHEX returns compact format hex string
- AT+MSG/CMSG/MSGHEX/CMSGHEX change "+xxx: Length error" to "+xxx: Length error MAXLEN"
- **AT+KEY=type,key** returns compact key string
- Class C downlink force return MSG type

1.2.3 Fixed Issue

- Fix AT+RXWIN2=freq,sf,bw command doesn't work issue
- Fix AT+LW=MC issue
- Fix AT+DELAY issue
- Class C mode error report "+xxx: Done" status

1.3 Related Products

Part Number	Bootloader	Interface
RHF76-052AM	UART	UART
RHF76-052CM	UART	UART

Table 1-1 Related products list

2 Preface

2.1 Conventions

- Command is case insensitive;
- All commands have response;
- Command length never exceeds total 528 characters;
- One valid AT Command must end with '\n', "\r\n" is also valid;
- If command timeout feature is enabled, end '\n' will not be mandatory;
- <LF> means the newline character. <CR> means carriage return;
- Default UART² configuration "9600, 8, n,1" (8 bits data, no parity, 1 stop bit);

2.2 Symbols

- = --> Set value for command
- ? --> Query
- : --> Start a list input parameter
- + --> Prefix of command
- , --> Separator of parameters
- Space --> Empty character, could be used to format command

NOTE: You could use quote sign <"> to force input parameter with space, such as <AT+MSGHEX="AA BB CC DD EE">, then "AA BB CC DD EE" is treated as one parameter. But if you input command <AT+MSGHEX=AA BB CC DD EE>, "AA BB CC DD EE" will treated as 5 parameters, AT+MSGHEX returns error.

2.3 Format

All commands in this document are end with <CR><LF>. In order to facilitate the description, all <CR><LF> is intentionally omitted in this document.

2.3.1 Query

Use query command to check LoRaWAN modem configuration, such as channel configuration, ADR status, TX power, etc.

```
AT+COMMAND
AT+COMMAND?
AT+COMMAND=?
```

NOTE: Query format is available with every LoRaWAN supported command

2.3.2 Configure / Control

Uses configure/control command to set new configuration or control transaction.

```
AT+COMMAND=DATA
```

2.3.3 Return

Return data is in format like "+CMD: RETURN DATA"

```
+COMMAND: "RETURN DATA"
```

² *RHF76-052AM supports UART interface*

RHF3M076 supports USB CDC interface of which UART configuration is unconcerned

2.4 Error

Code	Comment
-1	Parameters is invalid
-10	Command unknown
-11	Command is in wrong format
-12	Command is unavailable in current mode (Check with "AT+MODE")
-20	Too many parameters. LoRaWAN modem support max 15 parameters
-21	Length of command is too long (exceed 528 bytes)
-22	Receive end symbol timeout, command must end with <LF>
-23	Invalid character received
-24	Either -21, -22 or -23

Table 2- 1 Error code list

This error code list applies to all LoRaWAN supported command. User could refer to this list to know what is happening to LoRaWAN modem, when gets errors.

2.5 EEPROM

Items below will be synchronized to EEPROM of LoRaWAN modem once changed successfully, this makes LoRaWAN modem memorized, user doesn't need to reconfigure parameter after repower, LoRaWAN modem helps to keep it. If user wants to go back factory default configuration, refer to 4.21 FDEFAULT.

Item
Channel frequency, datarate range (up to 16 channels)
Datarate
TX power
ADR
RX Window2 frequency/datarate
RX Window1 frequency
Keys(NwkSkey, AppSkey, AppKey)
ID(DevAddr, DevEUI, AppEui)
Port
Unconfirmed message repetition
Confirmed message retry
Mode³
LWABP/LWOTAA
Customize data rate scheme
Delay(RX1, RX2, JRX1, JRX2)
Multicast parameters (MC_DevAddr, MC_NwkSkey, MC_AppSkey)

Table 2-2 Memorized configuration

³ Test mode is not stored; a reset during test mode makes modem switch back to previous mode.

3 Band Plans

Ai-Thinker RHF76-052AM / RHF76-052CM devices supports:

LoRaWAN 1.0.2 Band Plans:

EU868 US915 US915HYBRID CN779 EU433 AU915 AU915OLD CN470 AS923 KR920 IN865

Customized band plans:

CN470PREQUEL STE920

Refer to LoRaWANRegionalParametersv1.0.2_final_1944_1.pdf for details.

3.1 Data Rate Scheme

DR	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
0	SF12/125	SF10/125	SF10/125	SF12/125	SF12/125	SF12/125	SF10/125	SF12/125	SF12/125	SF12/125	SF12/125	SF12/125	SF12/125
1	SF11/125	SF9/125	SF9/125	SF11/125	SF11/125	SF11/125	SF9/125	SF11/125	SF11/125	SF11/125	SF11/125	SF11/125	SF11/125
2	SF10/25	SF8/125	SF8/125	SF10/25	SF10/25	SF10/125	SF8/125	SF10/25	SF10/25	SF10/25	SF10/25	SF10/25	SF10/25
3	SF9/125	SF7/125	SF7/125	SF9/125	SF9/125	SF9/125	SF7/125	SF9/125	SF9/125	SF9/125	SF9/125	SF9/125	SF9/125
4	SF8/125	SF8/500	SF8/500	SF8/125	SF8/125	SF8/125	SF8/500	SF8/125	SF8/125	SF8/125	SF8/125	SF8/125	SF8/125
5	SF7/125	-	-	SF7/125	SF7/125	SF7/125	-	SF7/125	SF7/125	SF7/125	SF7/125	SF7/125	SF7/125
6	SF7/250	-	-	SF7/250	SF7/250	SF8/500	-	-	SF7/250	-	SF7/250	-	SF7/250
7	FSK	-	-	FSK	FSK	-	-	-	FSK	-	FSK	-	FSK
8	-	SF12/500	SF12/500	-	-	SF12/500	SF12/500	-	-	-	-	-	-
9	-	SF11/500	SF11/500	-	-	SF11/500	SF11/500	-	-	-	-	-	-
10	-	SF10/500	SF10/500	-	-	SF10/500	SF10/500	-	-	-	-	-	-
11	-	SF9/500	SF9/500	-	-	SF9/500	SF9/500	-	-	-	-	-	-
12	-	SF8/500	SF8/500	-	-	SF8/500	SF8/500	-	-	-	-	-	-
13	-	SF7/500	SF7/500	-	-	SF7/500	SF7/500	-	-	-	-	-	-
14	-	-	-	-	-	-	-	-	-	-	-	-	-
15	-	-	-	-	-	-	-	-	-	-	-	-	-

Table 3-1 Data Rate Scheme

RF Modulation	Indicative physical bit rate [bit/s]
LoRa SF12/125KHz	250
LoRa SF11/125KHz	440
LoRa SF10/125KHz	980
LoRa SF9/125KHz	1760
LoRa SF8/125KHz	3125
LoRa SF7/125KHz	5470
LoRa SF7/250KHz	11000
FSK 50kbps	50000
LoRa SF12/500KHz	980
LoRa SF11/500KHz	1760
LoRa SF10/500KHz	3900
LoRa SF9/500KHz	7000
LoRa SF8/500KHz	12500
LoRa SF7/500KHz	21900

Table 3-2 RF Modulation Bit Rate

3.2 Payload Length Limitation

Repeater mode is not supported.

DR	EU868	US915	US915 HYBRID	CN779	EU433	AU915CR	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
0	51	11	11	51	51	51	11	51	51	65	51	51	51
1	51	53	53	51	51	51	53	51	51	151	51	51	51
2	51	126	126	51	51	51	126	51	51	242	51	51	51
3	115	242	242	115	115	115	242	115	115	242	115	115	115
4	242	242	242	242	242	242	242	242	242	242	242	242	242
5	242	-	-	242	242	242	-	242	242	242	242	242	242
6	242	-	-	242	242	242	-	-	242	-	242	-	242
7	242	-	-	242	242		-	-	242	-	242	-	242
8	-	53	53	-	-	53	53	-	-	-		-	-
9	-	129	129	-	-	129	129	-	-	-		-	-
10	-	242	242	-	-	242	242	-	-	-		-	-
11	-	242	242	-	-	242	242	-	-	-		-	-
12	-	242	242	-	-	242	242	-	-	-		-	-
13	-	242	242	-	-	242	242	-	-	-		-	-
14	-	-	-	-	-		-	-	-	-		-	-
15	-	-	-	-	-		-	-	-	-		-	-

Table 3-3 Data Rate and Payload Length Map

3.3 TX Output Power Encoding

TXPower	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
MaxEIRP	16	30	30	12.15 ⁴	12.15	30	30	19.15 ⁵	16	14	30	19.15	30
0~15	MaxEIRP – 2*TXPower												
0	16	30	30	12	12	30	30	20	16	14	30	20	20
1	14	28	28	10	10	28	28	18	14	12	28	18	18
2	12	26	26	8	8	26	26	16	12	10	26	16	16
3	10	24	24	6	6	24	24	14	10	8	24	14	14
4	8	22	22	4	4	22	22	12	8	6	22	12	12
5	6	20	20	2	2	20	20	10	6	4	20	10	10
6	4	18	18			18	18	8	4	2	18	8	8
7	2	16	16			16	16	6	2	0	16	6	6
8		14	14			14	14				14		
9		12	12			12	12				12		
10		10	10			10	10				10		
11-15													
TXPower Max	7	10	10	5	5	10	10	7	7	7	10	7	10
Default	1	8	8	0	0	8	8	0	0	1	8	0	4

Table 3-4 TX Power Table

⁴ 12.15dBm is set to 12dBm, MaxEIRP Index 2

⁵ 19.15dBm is converted to 20dBm, MaxEIRP Index 7

	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
MaxEIRP Index	5	13	13	2	2	13	13	7	5	4	13	7	13
MaxEIRP	16	30	30	12.15 ⁶	12.15	30	30	19.15 ⁷	16	14	30	19.15	30

Table 3-5 Default MaxEIRP Value and MaxEIRP Index Map

MaxEIRP Index	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
MaxEIRP	8	10	12	13	14	16	18	20	21	24	26	27	29	30	33	36

Table 3-6 MaxEIRP Table

TXPower is defined in LoRaWAN specification Mac command LinkADRReq chapter.

3.4 Channels

3.4.1 Default Uplink Channels

Band \ DR	0	1	2	3-95	Default Data Rate	Channel Numbers	Channel Numbers Max
EU868	868.1 DR0~DR5	868.3 DR0~DR5	868.5 DR0~DR5	-	0	3	16
US915	902.3 DR0~DR3	902.5 DR0~DR3	902.7 DR0~DR3	0~63 902.3 + ch * 200000 DR0~DR3 64~71 903.0 + ch * 600000 DR4	0	72	72
US915HYBRID	902.3 DR0~DR3	902.5 DR0~DR3	902.7 DR0~DR3	0~7 902.3 + ch * 200000 DR0~DR3 64 903.0 + ch * 600000 DR4	0	9	72
CN779	779.5 DR0~DR5	779.7 DR0~DR5	779.9 DR0~DR5	-	0	3	16
EU433	433.175 DR0~DR5	433.375 DR0~DR5	433.575 DR0~DR5	-	0	3	16
AU915	915.2 DR0~DR3	915.4 DR0~DR3	915.6 DR0~DR3	0~63 915.2 + ch * 200000 DR0~DR5 64~71 915.9 + ch * 600000 DR6	0	72	72
AU915OLD	915.2 DR0~DR3	915.4 DR0~DR3	915.6 DR0~DR3	0~63 915.2 + ch * 200000 DR0~DR3 64~71 915.9 + ch * 600000 DR4	0	72	72
CN470	470.3 DR0~DR5	470.5 DR0~DR5	470.7 DR0~DR5	200KHz channel space up to 95	0	96	96
AS923	923.2 DR0~DR5	923.4 DR0~DR5	-	-	2	2	16
KR920	922.1 DR0~DR5	922.3 DR0~DR5	922.5 DR0~DR5	-	0	3	16
IN865	865.0625 DR0~DR5	865.4025 DR0~DR5	865.985 DR0~DR5	-	0	3	16
CN470PREQUEL	471.5 DR0~DR5	471.7 DR0~DR5	471.9 DR0~DR5	200KHz channel space up to 7	0	8	16
STE920	922.0 DR0~DR5	922.2 DR0~DR5	922.4 DR0~DR5	200KHz channel space up to 7	0	8	16

Table 3-7 Default Uplink Channels

3.4.2 Downlink RXWIN1 Channels

Downlink Data Rate is defined by RX1DROffset.

Band \ CH	0-95
EU868	Same as uplink channels
US915	923.3 + (ch % 8) * 0.6
US915HYBRID	923.3 + (ch % 8) * 0.6
CN779	Same as uplink channels
EU433	Same as uplink channels
AU915	923.3 + (ch % 8) * 0.6

⁶ 12.15dBm is set to 12dBm, MaxEIRP Index 2

⁷ 19.15dBm is converted to 20dBm, MaxEIRP Index 7

Band \ CH	0~95
AU915OLD	$923.3 + (\text{ch \% } 8) * 0.6$
CN470	$500.3 + (\text{ch \% } 48) * 0.2$
AS923	Same as uplink channels
KR920	Same as uplink channels
IN865	Same as uplink channels
CN470PREQUEL	Same as uplink channels
STE920	Same as uplink channels

Table 3-8 Default Downlink RXWIN1 Channels

3.4.3 Downlink RXWIN2 Channel

Band\DR	Frequency/MHz	Data Rate
EU868	869.525	DR0
US915	923.3	DR8
US915HYBRID	923.3	DR8
CN779	786	DR0
EU433	434.665	DR0
AU915	923.3	DR8
AU915OLD	923.3	DR8
CN470	505.3	DR0
AS923	923.2	DR2
KR920	921.9	DR0
IN865	866.55	DR2
CN470PREQUEL	471.3	DR3
STE920	923.2	DR0

Table 3-9 Default RXWIN2 Configuration

3.4.4 Join Request Channels

Band	Channels
EU868	0-2
US915	All uplink channels
US915HYBRID	All uplink channels
CN779	0-2
EU433	0-2
AU915	All uplink channels
AU915OLD	All uplink channels
CN470	All uplink channels
AS923	0-1 (Fixed DR2)
KR920	0-2
IN865	0-2
CN470PREQUEL	0-7
STE920	0-7

Table 3-10 Join Request Channels

Note: Although the modem supports user to modify the default uplink channels, it does not encourage user to do so. If user need modify the default channels, please make sure gateway and server supports the selected channel.

3.5 Join Duty Cycle Limitation

The latest V2.1.x (or higher) firmware enables the global JoinReq duty cycle which applies below table⁸.

Time	Range	Transmit time	DutyCycle
Aggregated during the first hour following power-up or reset	$T_0 < t < T_0 + 1$	Transmit time < 36Sec	1%
Aggregated during the next 10 hours	$T_0 + 1 < t < T_0 + 11$	Transmit time < 36Sec	0.1%
After the first 11 hours, aggregated over 24h	$T_0 + 11 + N < t < T_0 + 35 + N$ (N>=0)	Transmit time < 8.7Sec per 24h	0.01%

Table 3- 11 Join Duty Cycle

"AT+LW=JDC, OFF" command could be used to disable the feature if user need to disable the feature.

3.6 RX1DROffset Limitation

RX1DROffset	EU868	US915	US915 HYBRID	CN779	EU433	AU915	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
Min	0	0	0	0	0	0	0	0	0	0	0	0	0
Max	5	3	3	5	5	5	3	5	7	5	7	5	5

Table 3- 12 RX1DROffset Range

3.6.1 EU868/EU434/CN470 /KR920/CN470PREQUEL/STE920

$$DR = \text{MAX}(\text{UplinkChannelDaraRate} - \text{RX1DROffset}, \text{DR0})$$

3.6.2 US915/ US915HYBRID/AU915

$$DR = \text{MAX}(\text{MIN}(\text{UplinkChannelDaraRate} + 10 - \text{RX1DROffset}, \text{DR13}), \text{DR8})$$

3.6.3 AS923

$$\text{MIN}(5, \text{MAX}(\text{MinDR}, \text{UplinkChannelDaraRate} - \text{Effective_RX1DROffset}))$$

MinDR depends on the DownlinkDwellTime bit sent to the device in the TxParamSetupReq command:

- Case DownlinkDwellTime = 0 (No limit): MinDR = DR0
- Case DownlinkDwellTime = 1 (400ms): MinDR = DR2

RX1DROffset	0	1	2	3	4	5	6	7
Effective_RX1DROffset	0	1	2	3	4	5	-1	-2

Table 3- 13 AS923 RX1DROffset Effective Table

3.6.4 IN865

$$\text{MIN}(5, \text{MAX}(0, \text{UplinkChannelDaraRate} - \text{Effective_RX1DROffset}))$$

RX1DROffset	0	1	2	3	4	5	6	7
Effective_RX1DROffset	0	1	2	3	4	5	-1	-2

Table 3- 14 IN865 RX1DROffset Effective Table

⁸ LoRaWAN102-20161012 Page 37

3.7 CFLIST

	EU868	US915	US915 HYBRID	CN779	EU433	AU915CR	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
ChId	3-7 ⁹	N/A	N/A	3-7	3-7	N/A	N/A	N/A	2-6	3-7	3-7	N/A	N/A

Table 3-15 CFList Definition

3.8 LinkAdrReq

ChMaskCntl	EU868	US915	US915 HYBRID	CN779	EU433	AU915CR	AU915OLD	CN470	AS923	KR920	IN865	CN470 PREQUEL	STE920
0	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15	0-15
1	RFU	16-31	16-31	RFU	RFU	16-31	16-31	16-31	RFU	RFU	RFU	16-31	RFU
2	RFU	32-47	32-47	RFU	RFU	32-47	32-47	32-47	RFU	RFU	RFU	32-47	RFU
3	RFU	48-63	48-63	RFU	RFU	48-63	48-63	48-63	RFU	RFU	RFU	48-63	RFU
4	RFU	64-71	64-71	RFU	RFU	64-71	64-71	64-79	RFU	RFU	RFU	64-79	RFU
5	RFU	RFU	RFU	RFU	RFU	RFU	RFU	80-95	RFU	RFU	RFU	80-95	RFU
6	All On	0-63 on Mask 64-71	0-63 on Mask 64-71	All On	All On	0-63 on Mask 64-71	0-63 on Mask 64-71	All On	All On	All On	All On	All On	All On
7	RFU	0-63 off 64-71 Mask	0-63 off 64-71 Mask	RFU	RFU	0-63 off 64-71 Mask	0-63 off 64-71 Mask	RFU	RFU	RFU	RFU	RFU	RFU

Table 3-16 LinkAdrReq ChMaskCntl Definition

3.9 Band Specific Limitation

3.9.1 US915/AU915/CN470 Channel Limitation

Under these modes, up to 72 (US915/AU915) or 96 (CN470) channels could be enabled. All these channels are not configurable with the default channels according to the definition of LoRaWAN 1.0.1. This means below commands will be invalid:

AT+CH=ch, freq, [drmin], [drmax]

AT+RXWIN1=ch, freq

To turn on/off channel, user need to use AT+CH=NUM or AT+CH=ch, ON/OFF command.

3.9.2 EU868 Duty Cycle Limitation

Only EU868 band need enable duty cycle limitation to comply with ETSI [EN300.220] standard. Band and limitation is defined as below.

Band Index	Frequencies(MHz)	Maximum Power	Duty Cycle	Band Width
g2	863.00 ~ 865.00	14dBm	0.1%	2MHz
g	865.00 ~ 868.00	14dBm	1%	3MHz
g1	868.00 ~ 868.60	14dBm	1%	600KHz
g2	868.70 ~ 869.20	14dBm	0.1%	500KHz
g3	869.40 ~ 869.65	27dBm	10%	250KHz

⁹ Here has some difference from LoRaWAN specification use 4-8 to define, by which it assume first channel has index 1. Ai-Thinker device use index 0 for the first channel.

Band Index	Frequencies(MHz)	Maximum Power	Duty Cycle	Band Width
g4	869.70 ~ 867.00	14dBm	1%	300KHz

Table 3-17 ETSI EU868 Regulation

3.9.3 CN799 Duty Cycle Limitation

Band Index	Frequencies(MHz)	Maximum Power	Duty Cycle	Band Width
g0	779.00 ~ 787.00	12.15dBm	1%	8MHz

Table 3-18 CN470 Duty Cycle Limitation

3.9.1 EU433 Duty Cycle Limitation

Band Index	Frequencies(MHz)	Maximum Power	Duty Cycle	Band Width
g0	433.175 ~ 434.665	12.15dBm	1%	8MHz

Table 3-19 CN470 Duty Cycle Limitation

3.9.2 AS923 Dwell Time Limitation

UplinkDwellTime, DownlinkDwellTime and MaxEIRP can be set configured through TxParamSetupReq / TxParamSetupAns MAC command.

DR \ DwellTime	UplinkDwellTime	UplinkDwellTime	DownlinkDwellTime	DownlinkDwellTime
	0	1	0	1
0	51	N/A	51	N/A
1	51	N/A	51	N/A
2	51	11	51	11
3	115	53	115	53
4	242	125	242	125
5	242	242	242	242
6	242	242	242	242
7	242	242	242	242
8:15	RFU	RFU	RFU	RFU

Table 3-20 AS923 Dwell Time Limitation

3.9.3 KR920 Channels and TX Power Limitation

For KR920 band, only below channels are available.

Channel Frequency	920.9	921.1	921.3	921.5	921.7	921.9	922.1	922.3	922.5	922.7	922.9	923.1	923.3
Maximum EIRP output power	10	10	10	10	10	10	14	14	14	14	14	14	14

Table 3-21 KR920 Channel and TX power limitation

3.10 Band Frequency Range

Band	Start Channels	End Frequency	Band Width
EU868	863	870	7MHz
US915	902	928	26MHz
US915HYBRID	902	928	26MHz
CN779	799	787	8MHz
EU433	433.175	434.665	1.49MHz
AU915	915	928	13MHz
AU915OLD	915	928	13MHz
CN470	470	510	40MHz
AS923	902	928	26MHz

Band	Start Channels	End Frequency	Band Width
KR920	920.9	923.3	2.4MHz
IN865	865	867	2MHz
CN470PREQUEL	470	510	40MHz
STE920	920	925	26MHz

3.10.1 AS923 Country Limitation¹⁰

Country Name	Frequency Range
Brunei	923-925
Cambodia	923-925
Indonesia	923-925
Japan	920-928
Laos	923-925
New Zealand	915-928
Singapore	920-925
Taiwan	922-928
Thailand	920-925
Vietnam	920-925

¹⁰ Defined by LoRaWAN 1.0.2 Regional Parameter

4 Commands

Command	Description
AT	Test command
FDEFAULT	Factory data reset
RESET	Software reset
DFU	Force bootloader to enter dfu mode
LOWPOWER	Enter sleep mode
VER	Version[Major.Minor.Patch]
MSG	LoRaWAN unconfirmed data
MSGHEX	LoRaWAN unconfirmed data in hex
CMSG	LoRaWAN confirmed data
CMSGHEX	LoRaWAN confirmed data in hex
PMSG	LoRaWAN proprietary
PMSGHEX	LoRaWAN proprietary in hex
CH	LoRaWAN channel frequency
DR	LoRaWAN datarate
ADR	LoRaWAN ADR control
REPT	Unconfirmed message repetition
RETRY	Confirmed message retry
POWER	LoRaWAN TX power
RXWIN2	LoRaWAN RX window2
RXWIN1	Customized RXWIN1 frequency
PORT	LoRaWAN communication port
MODE	LWABP, LWOTAA, TEST
ID	LoRaWAN DevAddr/DevEui/AppEui
KEY	Set NWKSKEY/APPSKEY/APPKEY
CLASS	Choose LoRaWAN modem class(A/B/C)
JOIN	LoRaWAN OTAA JOIN
LW	LoRaWAN misc configuration (CDR, ULDL, NET, DC, MC, THLD)
TEST	Send test serious command
UART	UART configure
DELAY	RX window delay
VDD	Get VDD
RTC	RTC time get/set
EEPROM	Write/Read EEPROM

Table 4-1 Command List

4.1 AT

Use to test if connection of module is OK. This is a dummy command just like other common "AT modules"

Format:

AT

Return:

+AT: OK

4.2 VER

Check firmware version. Versioning rule refers to [Semantic Versioning 2.0.0](#).

Format:

AT+VER

Return:

+VER: \$MAJOR.\$MINOR.\$PATCH

+VER: 2.1.x

4.3 ID

Use to check the ID of the LoRaWAN module, or change the ID. ID is treated as big endian numbers.

Read ID Format:

```
AT+ID // Read all, DevAddr(ABP), DevEui(OTAA), AppEui(OTAA)
AT+ID=DevAddr // Read DevAddr
AT+ID=DevEui // Read DevEui
AT+ID=AppEui // Read AppEui
AT+ID=DevAddr, "devaddr" // Set new DevAddr
AT+ID=DevEui, "deveui" // Set new DevEui
AT+ID=AppEui, "appeui" // Set new AppEui
```

Return:

```
+ID: DevAddr, xx:xx:xx:xx
+ID: DevEui11, xx:xx:xx:xx:xx:xx:xx:xx
+ID: AppEui12, xx:xx:xx:xx:xx:xx:xx:xx
```

Change end device address (**DEVADDR**)

```
AT+ID=DevAddr, "4 bytes length hex identifier"
eg: AT+ID=DevAddr, "01234567"
eg: AT+ID=DEVADDR, "01 23 45 67"
```

Return:

```
+ID: DevAddr, 01:23:45:67
```

Change device extended unique identifier (**DEVEUI**)

```
AT+ID= DevEui, "8 bytes length hex identifier (64bits)"
```

¹¹ DevEui which is supplied by Ai-Thinker are derived from STM32's UUID, these EUIs are Ai-Thinker unique is not standard IEEE EUI-64, , it is recommended to apply and use IEEE-EUI64.

¹² Default AppEui is **52:69:73:69:6E:67:48:46**

eg: AT+ID=DevEui, "0123456789ABCDEF"
 eg: AT+ID=DEVEUI, "01 23 45 67 89 AB CD EF"

Return:

+ID: DevEui, 01:23:45:67:89:AB:CD:EF

Change device extended unique identifier (**APPEUI**)

AT+ID= AppEui, "8 bytes length hex identifier (64bits)"

eg: AT+ID=AppEui, "0123456789ABCDEF"
 eg: AT+ID=APPEUI, "01 23 45 67 89 AB CD EF"

Return:

+ID: AppEui, 01:23:45:67:89:AB:CD:EF

4.4 RESET

Use to reset the module. If module returns error, then reset function is invalid.

Format:

AT+RESET

Return:

+RESET: OK

4.5 MSG

Use to send string format frame which is no need to be confirmed by the server.

Format:

AT+MSG="Data to send"

Return: *(Full return message)*

+MSG: Start
 +MSG: FPENDING
 +MSG: Link 20, 1
 +MSG: ACK Received
 +MSG: PORT: 8; RX: "12345678"
 +MSG: RXWIN2¹³, RSSI -106, SNR 4
 +MSG: Done

Below return messages are optional, it is returned only in the cases that specified event occurs.

+MSG: FPENDING	<i>// Downlink frame FPENDING flag is set</i>
+MSG: Link 20, 1	<i>// LinkCheckAns received</i>
+MSG: ACK Received	<i>// Downlink frame ACK flag is set</i>
+MSG: PORT: 8; RX: "12345678"	<i>// Downlink message is received</i>
+MSG: RXWIN2, RSSI -106, SNR 4	<i>// Downlink frame signal strength</i>

4.5.1 LinkCheckReq

AT+MSG could be used to send LinkCheckReq mac command to check Link status between modem and server.

¹³ **RXWIN2**: Message is received during RX Window2; **RXWIN1**: RX Window1; **RXWIN0**: Class C Extra RXWIN2.

AT+MSG*+MSG: Start**+MSG: TX ""**+MSG: Link 20, 1**+MSG: RXWIN1, RSSI -93, SNR 6.25**+MSG: Done*

From example above, the modem returns “*+MSG: Link 20, 1*” to host, it is in the format:

+MSG: Link Margin, GwCnt

The demodulation margin (*Margin*) is an 8-bit unsigned integer in the range of 0..254 indicating the link margin in dB of the last successfully received LinkCheckReq command.

A value of “0” means that the frame was received at the demodulation floor (0 dB or no margin) while a value of “20”, for example, means that the frame reached the gateway 20 dB above the demodulation floor. Value “255” is reserved.

The gateway count (*GwCnt*) is the number of gateways that successfully received the last LinkCheckReq command.

4.5.2 Error Status

1. LoRaWAN transaction service is ongoing
+MSG: LoRaWAN modem is busy
2. LoRaWAN modem is in OTAA mode and not joined a network
+MSG: Please join network first
3. LoRaWAN modem already joined to a network previously
+JOIN: Joined already

Note: use AT+JOIN=FORCE to force join if needed.

4. All configured channels are occupied by others.

+MSG: No free channel -70

Note: use AT+LW=THLD to set a new threshold

5. There is no band available for the moment. The modem must stay silence for a while, because of local regulation rules or Join Request Duty Cycle

+MSG: No band in 13469ms

6. Current DR set data rate is not supported

+MSG: DR error

Note: use AT+DR=dr to set a new datarate

7. Current payload length is too long to send.

+MSG: Length error N

Note: N could be 0 or none zero value, if it returns 0, it means there is a pending Uplink MAC Command must be sent through Port 0. User need send a dummy MSG command "AT+MSG" to flush uplink MAC command.

It is recommended for use to run AT+LW=LEN command to get maximum available payload size. And make sure the next packet payload length is less than the available maximum payload length.

Note: use AT+LW=LEN command to get current available length.

4.6 CMSG

Use to send string format frame which must be confirmed by the server.

Format:

```
AT+CMMSG="Data to send"
```

Return: *(Full return message)*

```
+CMMSG: Start
+CMMSG: Wait ACK
+CMMSG: FPENDING
+CMMSG: Link 20, 1
+CMMSG: ACK Received
+CMMSG: PORT: 8; RX: "12345678"
+CMMSG: RXWIN214, RSSI -106, SNR 4
+CMMSG: Done
```

Below return messages are optional, it is returned only in the cases that specified event occurs.

```
+CMMSG: FPENDING // Downlink frame FPENDING flag is set
+CMMSG: Link 20, 1 // LinkCheckAns received
+CMMSG: ACK Received // Downlink frame ACK flag is set
+CMMSG: PORT: 8; RX: "12345678" // Downlink message is received
+CMMSG: RXWIN215, RSSI -106, SNR 4 // Downlink frame signal strength
```

4.7 MSGHEX

Use to send hex format frame which is no need to be confirmed by the server.

Format:

```
AT+MSGHEX="xx xx xx xx"
eg: AT+MSGHEX="12345678"
```

Return:

```
+MSGHEX: Start
+MSGHEX: Done
```

For detailed examples, please refer to MSG. MSG and MSGHEX are the same command except payload format.

4.8 CMSGHEX

Use to send hex format frame which must be confirmed by the server.

Format:

```
AT+CMSGHEX="Data to send"
eg: AT+CMSGHEX="12345678"
```

Return:

```
+CMSGHEX: Start
+CMSGHEX: Wait ACK
+CMSGHEX: Done
```

For detailed examples, please refer to CMSG. CMSG and CMSGHEX are the same command except payload format.

¹⁴ **RXWIN2**: Message is received during RX Window2; **RXWIN1**: RX Window1; **RXWIN0**: Class C Extra RXWIN2.

¹⁵ **RXWIN2**: Message is received during RX Window2; **RXWIN1**: RX Window1; **RXWIN0**: Class C Extra RXWIN2.

4.9 PMSG

Use to send string format LoRaWAN proprietary frames.

Format:

```
AT+PMSG="Data to send"
eg: AT+PMSG="This is a string"
```

Return:

```
+PMSG: Start
+PMSG: Done
```

4.10 PMSGHEX

Use to send hex format LoRaWAN proprietary frames.

Format:

```
AT+PMSGHEX="Data to send"
eg: AT+PMSGHEX="AB CD"
```

Return:

```
+PMSGHEX: Start
+PMSGHEX: Done
```

4.11 PORT

Set PORT number which will be used by MSG/CMSG/MSGHEX/CMSGHEX command to send message, port number should range from 1 to 255. User should refer to LoRaWAN specification to choose port.

Format:

```
AT+PORT="port" // "port" should be 1~255
eg: AT+PORT=8 // Set port to 8
eg: AT+PORT=? // Check current port
```

Return:

```
+PORT: 8 // PORT query/set return
```

4.12 ADR

Set ADR function of LoRaWAN module.

Format:

```
AT+ADR="state"
eg: AT+ADR=ON // Enable ADR function
AT+ADR=OFF // Disable ADR function
AT+ADR=? // Check current ADR configuration
```

Return:

```
+ADR: ON // ADR query/set return
```

4.13 DR

Use LoRaWAN defined DRx to set datarate of LoRaWAN AT modem. Refer to **Chapter 3 Band Plans** about the detailed definition of LoRaWAN data rate.

4.13.1 Check and Set Data Rate

Format:

```
AT+DR // Check current selected DataRate
AT+DR=drx // "drx" should range 0~15
```

Return:

```
+DR: DR0
+DR: US915 DR0 SF10 BW125K
```

Return: (ADR is functional)

```
+DR: DR0 (ADR DR3)
+DR: US915 DR3 SF7 BW125K
+DR: US915 DR0 SF10 BW125K
```

4.13.2 Data Rate Scheme

Format:

```
AT+DR=band // "band" could be band names defined in Chapter 3 Band Plans
AT+DR=SCHEME // Check current band
```

Return: (EU868)

```
+DR: EU868
+DR: EU868 DR0 SF12 BW125K
+DR: EU868 DR1 SF11 BW125K
+DR: EU868 DR2 SF10 BW125K
+DR: EU868 DR3 SF9 BW125K
+DR: EU868 DR4 SF8 BW125K
+DR: EU868 DR5 SF7 BW125K
+DR: EU868 DR6 SF7 BW250K
+DR: EU868 DR7 FSK 50kbps
+DR: EU868 DR8 RFU
+DR: EU868 DR9 RFU
+DR: EU868 DR10 RFU
+DR: EU868 DR11 RFU
+DR: EU868 DR12 RFU
+DR: EU868 DR13 RFU
+DR: EU868 DR14 RFU
+DR: EU868 DR15 RFU
```

4.14 CH

4.14.1 Query Channel Configuration

Format:

```
AT+CH
AT+CH=ch
```

1. Check single channel frequency

```
eg: AT+CH=2
+CH: 2,868500000,DR0:DR5
```

2. Query all channels

```
AT+CH
```

Query All Channels Return Format:

```
+CH: TOTAL_CHANNEL_NUMBER; LCn,FREQn,DR_MINn,DR_MAXn; LCy,FREQy,DR_MINy,DR_MAXy; ...
```

```
LCz,FREQz,DR_MINz,DR_MAXz;
```

```
eg: +CH: 3; 0,868100000,DR0,DR5; 1,868300000,DR0,DR5; 2,868500000,DR0,DR5;
```

4.14.2 Add or Delete Channel

Set channel parameter of LoRaWAN modem, Set frequency zero to delete one channel.

Format:

```
AT+CH="chn", ["freq"], ["drmin"], ["drmax"]
// Change the chn channel frequency to "Freq"
// "freq" is in MHz.
// Available "drmin"/"drmax" range DR0 ~ DR15
```

1. Change channel CH3 frequency to 433.3MHz, datarate DR0~DR5
eg: AT+CH=3, 433.3, DR0, DR5
2. Delete channel CH3
eg: AT+CH=3, 0
3. Change channel CH0 frequency to 433.3MHz,DR7
eg: AT+CH=0, 433.3, DR7
4. Change channel CH3 frequency to 433.7MHz, datarate DR0~DR5
eg: AT+CH=3, 433.7, 0, 5
5. Change channel CH3 frequency to 433.7MHz, datarate DR7
eg: AT+CH=3, 433.7, DR7
6. Change channel CH3 frequency to 433.7MHz, with default datarate DR0~DR5
eg: AT+CH=?
eg: AT+CH=3, 433.7
// It is not recommended to use this command

Return:

```
+CH: 3,433700000,DR0:DR5
+CH: 3,433700000,DR1
```

4.14.3 Enable or Disable Channel

Format:

```
AT+CH=NUM
AT+CH=NUM, chm-chn, ..., chx-chy, chz
```

1. Check current enabled channels
eg: AT+CH=NUM
+CH: NUM, 0-7, 64
2. Enable and disable channels
eg: AT+CH=NUM, 0-5, 64 // Enable channel 0, 1, 2, 3, 4, 5 and 64, disable all others
+CH: NUM, 0-5, 64

Note: All channels should be controlled by a single command. The command operates all channels (0-95).

4.15 POWER

4.15.1 Set and Check Power

LoRaWAN TX power is controlled by internal TX power table, and also decided by hardware. Check TX power table to know what power could support.

Format:

```
AT+POWER
AT+POWER="pow"           // Change LoRaWAN Tx Power
eg: AT+POWER=14          // Change LoRaWAN AT module TX power to 14dBm
```

Return:

```
+POWER: 14
```

4.15.2 Force Set Power

This command can be used to set a fixed TX power for LoRaWAN modem, it will bypass LoRaWAN TX power table and LinkADDRReq command.

Format:

```
AT+POWER=pow, FORCE
```

4.15.3 Power Table

This command can be used to check band specific power table.

Format:

```
AT+POWER=TABLE
+POWER: 30 28 26 24 22 20 18 16 14 12 10
```

4.16 REPT

Unconfirmed message repeats times.

Format:

```
AT+REPT="Repeat Times" //Repeat times" should range 1~15
eg: AT+REPT=2           //Repeat 2 times
```

Return:

```
+REPT: 2
```

4.17 RETRY

Confirmed message retry times. Valid range 0~254, if retry times is less than 2, only one message will be sent.

Format:

```
AT+RETRY="Retry Times" //Retry times" should range 0~15
eg: AT+RETRY=3          //Retry 2 times (3-1), if no ack receive
```

Return:

```
+RETRY: 3
```

4.18 RXWIN2

Set second RX window frequency and Data Rate. This command will change RXWIN2 configuration, which may cause downlink lost, if configuration is wrong.

Format:

```
AT+ RXWIN2 // Query RX Window2 configuration
AT+RXWIN2=Frequency,DRx // Set frequency and datarate
AT+RXWIN2=Frequency,SFx,BW // Set RXWIN2 through SF and BW
eg: AT+RXWIN2=433.3,DR3 // Set RXWIN2 433.3MHz/DR3
eg: AT+RXWIN2=433.3,SF7,500 // Set RXWIN2 433.3MHz/SF7/BW500KHz
```

Return:

```
// General data rate
+RXWIN2: 433300000,DR5
// Customized RX Window2 data rate with spread factor and band width
+RXWIN2: 433000000,SF7,BW125K
```

From firmware 1.8.0, RXWIN2 command could support more flexible configuration. Both LoRaWAN defined data rate (combination of spread faction and band width) and LoRa defined spread factor and band width format are supported. User could set his RXWIN2 to any possible SF and BW scheme, which is a very useful function for LoRaWAN proof of concept.

4.19 RXWIN1

RXWIN1 command could be used to set customized RXWIN channel, each RXWIN channel maps to an uplink channel. When RXWIN1 is enabled, user need make sure every uplink channel has its own mapped RXWIN1 channel, or the modem may perform unexpected.

With this special RXWIN1 command, frequency shift between uplink and downlink becomes possible, then full-duplex is easy to achieve for the system if gateway supports.

a) Set RXWIN1

```
AT+RXWIN1=ch, freq
eg: AT+RXWIN1=0,868.9
```

Set none zero **freq** to overwrite default RXWIN1 channel frequency.

Set zero **freq** to use default frequency

b) Query RXWIN1 channel

```
AT+RXWIN1=ch
eg: AT+RXWIN1=0,868100000
```

c) Check RXWIN1

```
AT+RXWIN1
+RXWIN1: 3; 0,868100000; 1,868300000; 2,868500000;
```

AT+RXWIN1 and its subcommands always returns the channels which are enabled currently. If customized downlink channel is zero, then default downlink channels will be used.

4.20 KEY

Change LoRaWAN related AES-128 KEY. If wrong key is used, your LoRaWAN modem will be rejected by LoRaWAN server. Contact server administrator to know what key should use. All KEYS are unreadable for security, the one who forgets his KEY need rewrite with a new key.

Format:

Change network session key (NWKSKEY)

AT+KEY=NWKSKEY, "16 bytes length key"

eg: AT+KEY=NWKSKEY, "2B7E151628AED2A6ABF7158809CF4F3C"

eg: AT+KEY=NWKSKEY, "2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C"

Return:

+KEY: NWKSKEY 2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C

Change application session key (APPSKEY)

AT+KEY=APPSKEY, "16 bytes length key"

eg: AT+KEY=APPSKEY, "2B7E151628AED2A6ABF7158809CF4F3C"

eg: AT+KEY=APPSKEY, "2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C"

Return:

+KEY: APPSKEY 2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C

Change application session key (APPKEY)

AT+KEY=APPKEY, "16 bytes length key"

eg: AT+KEY=APPKEY, "2B7E151628AED2A6ABF7158809CF4F3C"

AT+KEY=APPKEY, "2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C"

Return:

+KEY: APPKEY 2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C

4.21 FDEFAULT

Reset LoRaWAN AT modem to factory default configuration.

Format:

```
AT+FDEFAULT
AT+FDEFAULT=Ai-Thinker
```

Return:

```
+FDEFAULT: OK
```

Item	Value
Mode	LoRaWAN ABP
Channel	3 default channels 868.1MHz 868.3MHz 868.5MHz
Datarate Range	DR0 : DR5
Unconfirmed Message Repetition	1
Confirmed Message Retry	3
Port	8
Datarate	DR0
ADR	ON
Power	14dBm
RXWIN2	869.525MHz, DR0
RXWIN1 Delay	1s
RXWIN2 Delay	2s
JOIN ACCEPT RXWIN1 Delay	5s
JOIN ACCEPT RXWIN2 Delay	6s
Listen Before Talk Threshold	-85dBm
EU868 Duty Cycle Limitation	OFF
LoRaWAN Public Network	ON
NwkSKey	2B7E151628AED2A6ABF7158809CF4F3C
AppSKey	2B7E151628AED2A6ABF7158809CF4F3C
AppKey	2B7E151628AED2A6ABF7158809CF4F3C
AppEui	52:69:73:69:6e:67:48:46
Uplink Counter	1
Downlink Counter	0
Multicast	OFF

Table 4-2 Factory default configuration

NOTE: Customized modem may be precompiled to use a different factory default configuration. If any user has request, please contact Ai-Thinker support@Ai-Thinker.com.

4.22 DFU

Use to enter DFU mode. If user need to enter DFU mode to update LoRaWAN modem firmware, then user should first send "AT+DFU=ON" command to enable firmware upgrade. Once DFU mode is on, user should repower LoRaWAN modem (unplug and plug back), after repowered LoRaWAN will enter DFU mode, user could use DfuSe tool to update the firmware. If user want to exit DFU mode without upgrade, user just need to repower again, LoRaWAN modem will exit DFU mode automatically.

For UART bootloader, "AT+DFU=ON" command will make device enter bootloader mode automatically.

Format:

```
AT+DFU="New state"
eg: AT+DFU=ON           // Enable DFU function
eg: AT+DFU=OFF         // Disable DFU function
AT+DFU=?               // Check if DFU is enabled configuration
```

Return:

```
+DFU: ON
+DFU: OFF
```

Example:

```
+DFU: ON
```

Note: DFU mode is risky. Before updating, user must make sure the firmware is supplied by Ai-Thinker, a wrong firmware may brick LoRaWAN modem.

4.23 MODE

Use to select work mode. LWABP¹⁶, LWOTAA¹⁷, TEST are supported. LoRaWAN modem can only work with one mode at a time. By default, LWABP is enabled, all test commands are unavailable, LoRaWAN will return error(-12) if it receives test command in non-test mode.

"AT+MODE" command will reset LoRaWAN stack when first enter LWABP/LWOTAA mode and reset LoRa chip when first enter test mode.

LWABP/LWOTAA mode status is remembered by LoRaWAN modem, each time LoRaWAN modem starts, it will enter previous working mode before reset or repower.

Format:

```
AT+MODE="mode"
eg: AT+MODE=TEST       // Enter TEST mode
eg: AT+MODE=LWOTAA     // Enter LWOTAA mode
eg: AT+MODE=LWABP      // Enter LWABP mode
```

Return

```
+MODE: LWABP           // Enter LWABP mode successfully
+MODE: LWOTAA          // Enter LWOTAA mode successfully
+MODE: TEST             // Enter TEST mode successfully
```

4.24 JOIN

When OTAA mode is enabled, JOIN command could use to join a known network.

Format:

```
AT+JOIN
AT+JOIN=FORCE
```

1. Join

¹⁶ LWABP is short for **L**oRa**W**AN **A**ctivation **B**y **P**ersonalization. Check <LoRaWAN™ Specification> for details

¹⁷ LWOTAA is short for **L**oRa**W**AN **O**ver-**T**he-**A**ir-**A**ctivation.

eg: AT+JOIN // Send JOIN request

2. Disconnect with current network, force send one JOIN request

eg: AT+JOIN=FORCE

3. Returns

- a) Join successfully

+JOIN: Starting

+JOIN: NORMAL

+JOIN: NetID 000024 DevAddr 48:00:00:01

+JOIN: Done

- b) Join failed

+JOIN: Join failed

- c) Join process is ongoing

+JOIN: LoRaWAN modem is busy

4.25 CLASS

This command could enable LoRaWAN modem to work at different mode (Class A/B¹⁸/C). LoRaWAN modem works at class A mode when power on, user need manually switch mode to class B/C as needed.

Format:

eg: AT+CLASS=A // Enable Class A mode

eg: AT+CLASS=C // Enable Class C mode

Return

+CLASS: A

4.25.1 Class C Downlink

Class C mode will reuse RXWIN2 configuration. Check with "AT+RXWIN2". If downlink is received, below message could be returned to host.

+MSG: FPENDING

+MSG: Link 20, 1

+MSG: ACK Received

+MSG: PORT: 8; RX: "12 34 56 78"

+MSG: RXWIN0, RSSI -106, SNR 4

+MSG: Done

4.26 DELAY

RX window delay configuration command. Supports configure RECEIVE_DELAY1, RECEIVE_DELAY2, JOIN_ACCEPT_DELAY1, JOIN_ACCEPT_DELAY2.

Command	Item	Comments
AT+DELAY=RX1, ms	RECEIVE_DELAY1	RX window 1 delay time
AT+DELAY=RX2, ms	RECEIVE_DELAY2	RX window 1 delay time
AT+DELAY=JRX1, ms	JOIN_ACCEPT_DELAY1	Join accept RX window 1 delay time

¹⁸ Class B is unavailable in current version

AT+DELAY=JRX2, ms

JOIN_ACCEPT_DELAY2

Join accept RX window 2 delay time

Table 4-3 LoRaWAN Delay Items

Format:

```
// Query delay settings
AT+DELAY
AT+DELAY?
AT+DELAY=?

// Set delay
AT+DELAY=RX1, 1000 // Unit: ms
AT+DELAY=RX2, 2000
AT+DELAY=JRX1, 5000
AT+DELAY=JRX2, 6000
```

Return:

```
+DELAY RX1, 1000
+DELAY RX2, 2000
+DELAY JRX1, 5000
+DELAY JRX2, 6000
```

4.27 LW

LW commands is a collection of several LoRaWAN control commands. Include CDR, ULDL, DC, NET, MC, THLD.

4.27.1 CDR

CDR is for customized data rate control, this command could be used to specify the valid data rate range of uplink packet and downlink packet.

Format:

AT+LW=CDR, [UL_DR_MIN, UL_DR_MAX, DL_DR_MIN, DL_DR_MAX]

1. Check current datarate limitation

```
AT+LW=CDR
+LW: CDR, TXDR(0,7), RXDR(0,7) //EU868
+LW: CDR, TXDR(0,4), RXDR(8,13) //AU920
```

2. Set customized data rate limitation, this command is only valid when customized data rate mode is enabled

```
AT+DR=CUSTOM
AT+LW=CDR, 0,7,0,7
+LW: CDR, TXDR(0,7), RXDR(0,7)
```

4.27.2 ULDL

Set and read uplink and downlink counter.

Format:

AT+LW=ULDL, UL_COUNTER, DL_COUNTER

1. Read counter

```
AT+LW=ULDL
+LW: ULDL 1, 0
```

2. Set counter

AT+LW=ULDL, 5, 10

+LW: ULDL 5, 10

4.27.3 DC

EU868 Duty Cycle limitation and LoRaWAN Transmit Duty Cycle control interface. This option is mandatory to be set to on, when using in Europe to follow ETSI regulation. And this command could also be used to set a specify value for **MaxDCycle**, valid range 0 ~ 15. And the tansmit aggregated duty cycle is allowed by:

$$AggregatedDutyCylce = \frac{1}{2^{MaxDCycle}}$$

A value of 0 corresponds to “no duty cycle limitation” except the one set by the regional regulation.

MaxDCycle	$2^{MaxDCycle}$	Aggregated Duty Cycle
0	1	100.000%
1	2	50.000%
2	4	25.000%
3	8	12.500%
4	16	6.250%
5	32	3.125%
6	64	1.563%
7	128	0.781%
8	256	0.391%
9	512	0.195%
10	1024	0.098%
11	2048	0.049%
12	4096	0.024%
13	8192	0.012%
14	16384	0.006%
15	32768	0.003%

Table 4-4 Duty Cycle Control

Format:

AT+LW=DC, "ON/OFF"

AT+LW=DC, MaxDCycle

Return format:

+LW=DC, "ON/OFF", MaxDCycle

1. Check DC option

AT+LW=DC

+LW: DC, ON, 0 // EU868 Duty Cycle ON, MaxDCycle is 0

2. Set EU868 ETSI Duty Cycle on

AT+LW=DC, ON

+LW: DC, ON, 0 //

3. Set EU868 ETSI Duty Cycle off

AT+LW=DC, OFF

+LW: DC, OFF

4. Set LoRaWAN MaxDCycle

AT+LW=DC

+LW: DC, ON, 0 // EU868 Duty Cycle ON, MaxDCycle is 0

+LW: DC, OFF, 1 // EU868 Duty Cycle OFF or not in EU868 mode, MaxDCycle is 0

4.27.4 NET

This command is used to choose public LoRaWAN network or private network. Set ON to choose public network, set OFF to choose private network.

Format:

AT+LW=NET, "ON/OFF"

1. Check network type

AT+LW=NET

+LW: NET, ON

2. Set public network on

AT+LW=NET, ON

+LW: NET, ON

3. Set public network off

AT+LW=NET, OFF

+LW: NET, OFF

4.27.5 MC

MC command could enable an extra broadcast address for LoRaWAN modem. This command is useful when using Class C mode, to control a group of devices which has the same multi cast address at the same time to use a broadcast command.

Format:

AT+LW=MC, ["ON/OFF"], ["DEVADDR"], ["NWKSKEY"], ["APPSKEY"], ["COUNTER"]

1. Check multi cast status

AT+LW=MC

+LW: MC, OFF, 00cf3e72, 0

2. Set MC parameters

AT+LW=MC,ON,"11223344","2B7E151628AED2A6ABF7158809CF4F3C","2B7E151628AED2A6ABF7158809CF4F3C",0

+LW: MC, ON, 11223344, 0

Default MC_NWKSKEY and MC_APPKEY both are **2B7E151628AED2A6ABF7158809CF4F3C**.

4.27.6 THLD

Listen before talk threshold control, available value -55 ~ -105 (dBm).

Format:

AT+LW=THLD, thresh_hold

1. Check current threshold level

AT+LW=THLD

+LW: THLD, -90

2. Set new threshold

AT+LW=THLD, -85

+LW: THLD, -85

4.27.7 BAT

Set DevStatusReq/DevStatusAns battery level value. Available value 0 ~ 255

1. Check current threshold level

```
AT+LW=BAT
+LW: BAT, 255
```

2. Set new threshold

```
AT+LW=BAT, 100
+LW: BAT, 100
```

4.27.8 TPS

TPS command can be used to set default TX parameter. **UplinkDwellTime** and **DownlinkDwellTime** option is just for AS923. **MaxEIRP** is for all bands.

Format:

```
AT+LW=TPS
AT+LW=TPS, UplinkDwellTime, DownlinkDwellTime, MaxEIRP
UplinkDwellTime: ON/OFF
DownlinkDwellTime: ON/OFF
MaxEIRP: 0~15
```

Return:

```
+LW: TPS, UplinkDwellTime, DownlinkDwellTime, MaxEIRP
```

Example:

```
AT+LW=TPS, ON, ON, 7
+LW: TPS, ON, ON, 7
```

4.27.9 SCR

SCR (Sequence counter Checking Relaxed) command could be used to disable strict downlink frame counter checking. Which is useful for some application, especially in the case which server can't reset downlink counter automatically.

Format:

```
AT+LW=SCR
AT+LW=SCR, ON
AT+LW=SCR, OFF
```

Return

```
+LW: SCR, OFF
+LW: SCR, ON
```

NOTE: If SCR is enabled, there may be security issue, if some recorder downlink and replay back to your device. Be careful to use this command.

4.27.10 JDC

JDC command could be used to disable the JoinRequest duty cycle limitation.

Format:

```
AT+LW=JDC
AT+LW=JDC, OFF
AT+LW=JDC, ON
```

Return:

```
+LW: JDC, ON
+LW: JDC, OFF
```

4.27.11 LEN

LEN command can be used to get maximum payload length which is supported to send according to current data rate.

Format:

```
AT+LW=LEN
```

Return:

```
+LW: LEN, 50
```

Note: If "AT+LW=LEN" returns 0 length. User must send a dummy AT+MSG command to flush the internal MAC command buffer. And continue to send more data.

4.28 WDT

WDT command can be used to turn on/off internal watchdog. The watchdog is on by default, this will enhance the module stability, especially under the condition of severe electromagnetic environment. After WDT is turned on, the sleep current will be increased by around 0.7uA.

Format:

```
AT+WDT
AT+WDT=ON
AT+WDT=OFF
```

Return:

```
+WDT: ON
+WDT: OFF
```

4.29 LOWPOWER¹⁹

Sleep command could be used to make modem enter sleep mode with ultra-low power consumption, check device datasheet to know detailed parameters. After device enters in sleep mode, host device could send any character to wakeup it, after this host should wait at least 5ms to send next commands, so that modem could get ready. A C code example is attached to show how to handle LOWPOWER mode.

During the LOWPOWER mode, level of UART RX pin must keep unchanged, any signal on UART RX pin will make modem exit LOWPOWER mode. When LOWPOWER mode is triggered, there are extra 30ms before modem really enter sleep mode, host device should use this time to de-initial its UART if it is needed.

It also supplies feature to set a lowpower alarm from 100ms to 129600000ms (36hrs).

Format:

```
eg: AT+LOWPOWER // Sleep until woke up by UART TX
eg: AT+LOWPOWER=100020 // Sleep 1000ms until timeout
eg: AT+LOWPOWER=AUTOON // Enter extremely low power mode
eg: AT+LOWPOWER=AUTOOFF // Exit extremely low power mode
```

¹⁹ RHF76-052AM (UART enabled) supports this feature, RHF3M076 (USB enabled) doesn't support sleep mode.

²⁰ Available after v1.9.5

// Query symbol is not available

Return

```
+LOWPOWER: SLEEP           // Enter SLEEP mode successfully
U+LOWPOWER: WAKEUP        // Modem is woke up.
```

Example:

```
AT+LOWPOWER=1000
U+LOWPOWER: WAKEUP
```

Note: Extra 0x55 will be sent to host mcu to perform a wakeup signal for it, LoRaWAN AT Modem will wait for 15ms before sending "+LOWPOWER: WAKEUP" frame , host MCU could use this 15ms to initialize then to receive the WAKEUP frame.

C example:

```
printf("AT+LOWPOWER\r\n");// Set low-power mode
// ...
// HOST do other operation.
// ...
printf("A");           // Send any character to wake-up the modem
DelayMs(5);           // Wait modem ready
printf("AT+ID\r\n");  // New operation
```

4.29.1 Low Power Auto Mode

AT+LOWPOWER=AUTOON command could be used to enable extremely low power mode. In this mode modem will enter deep sleep mode when it is idle. The idle status means no ongoing receiving commands, no ongoing LoRaWAN service needed. If this mode is enabled, when sending commands to modem, at least four 0xFFs need to be added to the start of each AT command. At the same time, each return message is also added with four 0xFFs. The host mcu parser should be able to handle these wakeup characters.

Example to send AT+ID command with low power auto mode

0xFF	0xFF	0xFF	0xFF	'A'	'T'	'+'	'I'	'D'	'\r'	'\n'
------	------	------	------	-----	-----	-----	-----	-----	------	------

Use AT+LOWPOWER=AUTOOFF command to turn off low power auto mode, four 0xFFs are also needed to add to the start of the command.

FF	FF	FF	FF	A	T	+	L	O	W	P	O	W	E	R	=	A	U	T	O	O	F	F	\r	\n
FF	FF	FF	FF	61	74	2B	6C	6F	77	70	6F	77	65	72	3D	61	75	74	6F	6F	66	66	0D	0A

Below hex string equals to the table above, send it to modem in hex format could also disable the low power auto on feature.

FFFFFFFF61742B6C6F77706F7765723D6175746F6F66660D0A

C example:

```
uint8_t buf[256];
printf("AT+LOWPOWER=AUTOON\r\n");// Set low-power auto on mode
// ...
// HOST do other operation.
// ...
buf[0] = 0xFF;
buf[1] = 0xFF;
```

```
buf[2] = 0xFF;
buf[3] = 0xFF;
//DelayMs(5); // If user use higher baud rate than 9600, uncomment this line
sprintf(buf+4, "AT+MSG=\"string\"\\r\\n");
uart_putbuf(buf, strlen(buf+4)+4); // Send command to LoRaWAN modem
```

4.30 VDD

Get supply voltage, return value in unit 0.01V. Format:

```
AT+VDD
AT+VDD?
AT+VDD=?
```

Example:

```
AT+VDD
+VDD: 3.30V
```

4.31 RTC

Get real time from LoRaWAN modem. When modem is powered on, it always starts from 2000-01-01 00:00:00, user could set new time to modem to sync to the real time.

1. Check current time

```
AT+RTC
+RTC: 2000-01-01 01:00:28 // this means the modem has kept running for 1 hour
```

2. Set new time to "2016-06-14 18:16:11", this format is very critical, must keep the same format as "yyyy-MM-dd HH:mm:ss", year must starts with 20xx.

```
AT+RTC="2016-06-14 18:16:11"
+RTC: 2016-06-14 18:16:11
```

4.32 EEPROM

LoRaWAN Modem supports maximum 256 bytes to save user data. Format:

```
AT+EEPROM=ADDR
AT+EEPROM=ADDR,VAL
```

Return:

```
+EEPROM: ADDR, VAL
```

Both ADDR and VAL are in hex format. Valid range is 0x00 ~ 0xFF. Example:

```
AT+EEPROM=00, AB
+EEPROM: 00, AB
```

4.33 UART

4.33.1 TIMEOUT

LoRaWAN AT modem supports UART receive timeout feature, AT parser inside the modem start counts from first "AT" character is received, when counter overflows, a "Input timeout" event will be triggered. One message like below will be showed. Maximum timeout value is 300ms.

```
+INFO: Input timeout
```

```
AT+UART=TIMEOUT, 0 // Disable timeout feature
AT+UART=TIMEOUT, 1000 // Set timeout 1s feature
```


AT+UART=TIMEOUT

// Get timeout value

4.33.2 BR

BR command could be used to set new baud rate. Available baud rate are 9600 14400 19200 38400 57600 76800 115200 and 230400. New baud rate will be validated after reset or repower.

Format:

AT+UART=BR

AT+UART=BR, br

Return:

+UART=BR, br

4.34 TEST

TEST command is not like other command, it is a serious command, includes several sub-commands, refer to table below. With test mode, user could do RF performance test quickly without any knowledge of LoRa chip. Commands which are related to RF configuration is disabled in test mode.

Sub-Command	Comment
STOP	Set LoRaWAN Modem to TEST stop mode
TXCW	Transmit continuous wave
TXCLORA	Transmit continuous LoRa signal
RFCFG	Set RF configuration in TEST mode
RXLRPKT	Continuous receive pure LoRa packet, print once there is new packet received
TXLRPKT	Send one HEX format packet out
TXLRSTR	Send one string format packet
RSSI	Get RSSI value of specified channel
LWDL	Send LoRaWAN downlink packet, useful tool to test CLASS C device

Table 4-5 TEST mode sub-command list

4.34.1 Help Information

```

STOP -- AT+TEST=STOP
HELP -- AT+TSET=HELP
TXCW -- AT+TEST=TXCW
TXCLORA -- AT+TEST=TXCLORA
RFCFG -- AT+TEST=RFCFG, [F], [SF], [BW], [TXPR], [RXPR], [POW], [CRC], [IQ], [NET]
RXLRPKT -- AT+TEST=RXLRPKT
TXLRPKT -- AT+TEST=TXLRPKT, "HEX"
TXLRSTR -- AT+TEST=TXLRSTR, "TEXT"
RSSI -- AT+TEST=RSSI, F, [CNT]
LWDL -- AT+TEST=LWDL, TYPE, DevAddr, "HEX", [FCNT], [FPORT], [FCTRL]
    
```

["]" means the parameter is omissible together with parameters behind it

4.34.2 Enter TEST mode

Before use any TEST command, LoRaWAN should work in test mode, or error code -12 will be reported.

Command:

```
AT+MODE=TEST
```

Return:

```
+MODE: TEST // LoRaWAN modem enter TEST mode successfully
```

4.34.3 Query RF configuration

First thing after enter TEST mode should be check RF configuration.

Command:

```
AT+TEST=? // Query test mode and RF configuration
```

Return Error:

```
+TEST: ERROR(-12)
```

When come with ERROR(-12), user could try "AT+MODE=?" to check if LoRaWAN modem is in TEST mode, if not user should enter test mode first.

Return STOP:

```
+TEST: STOP
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF,
NET:ON
```

Return TXLRPKT:

```
+TEST: TXLRPKT
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF,
NET:ON
```

Return RXLRPKT:

```
+TEST: RXLRPKT
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF,
NET:ON
```

Return TXCW:

```
+TEST: TXCW
+TEST: RFCFG F:433300000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF,
NET:ON
```

4.34.4 Set RF Configuration

RFCFG supports set frequency, SF, band width, TX preamble, RX preamble and TX power settings. TX and RX shares all configuration except "preamble length", user could choose different preamble length. For LoRa communication, it is strongly recommended to set RX preamble length longer than TX's. Bandwidth only supports 125KHz / 250KHz / 500KHz.

Depend on Semtech SX1276 (PA_BOOST/RFO) and design solution of Ai-Thinker module, MAX output power of different band LoRaWAN modem could be different. Check below table about the details.

Device	Bootloader	Interface	LF Band ²¹	HF Band ²²
RHF76-052AM	UART	UART	20dBm	14dBm
RHF76-052CM	UART	UART	-	20dBm

Table 4-6 MAX output power of HF and LF band

Format:

"[]" means the parameter is omissible together with parameters after it

AT+TEST=RFCFG,[FREQUENCY],[SF],[BANDWIDTH],[TX PR],[RX PR],[TX POWER],[CRC],[IQ],[NET]

eg: AT+TEST=RFCFG,866,SF12,125,12,15,14,ON,OFF,OFF

FREQUENCY: 866MHz

SpreadFactor: SF12

BandWidth: 125KHz

TX Preamble: 12

²¹ LF Band: Frequency is less than 525MHz

²² HF Band: Frequency is larger than 525MHz

```

RX Preamble:    15
Power:         14dBm
CRC:           ON
Inverted IQ:   OFF
Public LoRaWAN: OFF

```

Return:

```
+TEST: RFCFG F:868100000, SF12, BW125K, TXPR:8, RXPR:8, POW:14dBm, CRC:ON, IQ:OFF, PNET:ON
```

4.34.5 TX LoRa Packet

After enter test mode, user could send LoRa packet through "AT+TEST=TXLRPKT" sub-command. The command format is like below:

```
AT+TEST=TXLRPKT, "HEX STRING"
```

Command sequence to send LoRa packet:

```

// Set test mode
AT+MODE=TEST
// Query test mode, check RF configuration
AT+TEST=?
// Set RF Configuration
AT+TEST=RFCFG, [FREQUENCY], [SF], [BANDWIDTH], [TXPR], [RXPR], [POW], [CRC], [IQ], [NET]
// Send HEX format packet
AT+TEST=TXLRPKT, "HEX String"
eg:AT+TEST=TXLRPKT, "00 AA 11 BB 22 CC"
// Send TEXT format packet
AT+TEST=TXLRSTR, "TEXT"
eg:AT+TEST=TXLRSTR, "LoRaWAN Modem"

```

Return:

```

+TEST: TXLRPKT "404EA99000800A00089F6E770959"
+TEST: TXLRSTR "LoRaWAN Modem"
+TEST: TX DONE

```

4.34.6 RX LoRa Packet

After enter test mode, user could enter LoRa packet continuous RX mode through RXLRPKT sub-command. Like below:

```
AT+TEST=RXLRPKT
```

Command sequence to receive LoRa packet:

```

// Set test mode
AT+MODE=TEST
// Query test mode, check RF configuration
AT+TEST=?
// Set RF Configuration
AT+TEST=RFCFG, [FREQUENCY], [SF], [BANDWIDTH], [TXPR], [RXPR], [POW], [CRC], [IQ], [NET]
// Enter RX continuous mode
AT+TEST=RXLRPKT

```

Return:

```
+TEST: LEN:250, RSSI:-106, SNR:10
+TEST: RX 404EA99000800A00089F6E770959
```

4.34.7 TX Continuous Wave

Before enable TXCW function, right frequency and TX power should be set. Format:

```
AT+TEST=TXCW
```

Return:

```
+TEST: TXCW
```

4.34.8 TX Continuous LoRa

Before enable TXCLORA function, right frequency and TX power should be set. Format:

```
AT+TEST= TXCLORA
```

Return:

```
+TEST: TXCLORA
```

4.34.9 RSSI

Read RSSI from a specified channel. Format:

```
AT+TEST = RSSI, frequency(MHz), [times]
```

Return:

```
+TEST: RSSI, average, maximum, minimum
```

4.34.10 LWDL

LWDL command is designed to test LoRaWAN modem CLASS C function. Use this command, user can easily send data to a working LoRaWAN Class C device.

```
AT+TEST = LWDL, TYPE, "DevAddr", "HEX STRING", [FCNT], [FPORT], [FCTRL]
```

Return:

```
AT+TEST=LWDL,MSG,"009291ad","14 54 54 88 08 93 122 35", 1, 5, 00
+TEST: LWDL "A0AD91920000010005134D37EA53E3023A9F0125D234"
+TEST: LWDL TX DONE
```

Revision

V4.2 2017-05-15

- + Sync to FW v2.1.10

V4.1 2017-05-15

- + Updated Chapter 3 Band Plans
- + Added AT+LW=LEN command
- + Added AT+LW=JDC command
- + Updated MSG/CMSG/MSGHEX/CMSGHEX

V4.0 2017-05-14

- + Sync to FW v2.1.7

V3.2 2017-02-18

- + Sync to FW v2.0.10
- + Add command description AT+LW=BAT
- + Fix AT+MSG output

V3.1 2016-06-30

- + Sync to FW v2.0.4
- + Add LinkCheckReq

V3.0 2016-06-26

- + Sync to FW v2.0.2
- + Support sending LoRaWAN proprietary frame
- + RETRY command to set confirmed message retry times
- + RXWIN1 is updated
- + JOIN command is simplified
- + Multi cast feature
- + LW command to change LBT threshold configuration
- + LOWPOWER command alarm feature, add timer to sleep mode
- + RTC yyyy-MM-dd HH:mm:ss
- + VDD command to read supply voltage
- + REG command to control SX1276 RF chip register directly (Merge PS01510)
- + EEPROM command

V2.4 2015-12-03

- + Sync to FW v1.9.1

V2.3 2015-11-26

- + Maximum payload size 255 bytes
- + Add AT+DELAY command
- + AT+DR=CUSTOM command FSK support

V2.1 2015-11-24

- + Fix typo
- + Remove all tedious <CR><LF>

V2.0 2015-11-18

- + Add RXWIN1 command
- + Add RXWIN2 SF and BW format command
- + Add AT+TEST=RFCFG command
- + Update DR, supports customized data rate scheme
- + Update doc for LoRaWAN mode firmware V1.8.0

V1.6 2015-09-11

- + AT+DR=BAND, AT+TEST=RSSI
- + Update doc for LoRaWAN mode firmware V1.6.8

V1.5 2015-09-04

- + Add "LOWPOWER" command to enable LowPower Mode
- + Add commands CH, PORT, JOIN, UART
- + Update ID, DR, TEST,
- + Update doc for LoRaWAN mode firmware V1.6.0

V1.2 2015-06-04

- + Add "CLASS" command to enable LoRaWAN Class C
- + Update doc for LoRaWAN mode firmware V1.2.6

V1.1 2015-05-14

- + Update "2.4 Error"
- + Fix typo
- + Add content about LoRaWAN output power
- + Update doc for LoRaWAN mode firmware V1.2.4

V1.0 2015-05-09

- + Use new template
- + Doc is for LoRaWAN mode firmware V1.1.0

Please Read Carefully:

Information in this document is provided solely in connection with Ai-Thinker products. Ai-Thinker reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All Ai-Thinker products are sold pursuant to Ai-Thinker's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the Ai-Thinker products and services described herein, and Ai-Thinker assumes no liability whatsoever relating to the choice, selection or use of the Ai-Thinker products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by Ai-Thinker for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN Ai-Thinker'S TERMS AND CONDITIONS OF SALE Ai-Thinker DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF Ai-Thinker PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

Ai-Thinker PRODUCTS ARE NOT DESIGNED OR AUTHORIZED FOR USE IN: (A) SAFETY CRITICAL APPLICATIONS SUCH AS LIFE SUPPORTING, ACTIVE IMPLANTED DEVICES OR SYSTEMS WITH PRODUCT FUNCTIONAL SAFETY REQUIREMENTS; (B) AERONAUTIC APPLICATIONS; (C) AUTOMOTIVE APPLICATIONS OR ENVIRONMENTS, AND/OR (D) AEROSPACE APPLICATIONS OR ENVIRONMENTS. WHERE Ai-Thinker PRODUCTS ARE NOT DESIGNED FOR SUCH USE, THE PURCHASER SHALL USE PRODUCTS AT PURCHASER'S SOLE RISK, EVEN IF Ai-Thinker HAS BEEN INFORMED IN WRITING OF SUCH USAGE, UNLESS A PRODUCT IS EXPRESSLY DESIGNATED BY Ai-Thinker AS BEING INTENDED FOR "AUTOMOTIVE, AUTOMOTIVE SAFETY OR MEDICAL" INDUSTRY DOMAINS ACCORDING TO Ai-Thinker PRODUCT DESIGN SPECIFICATIONS. PRODUCTS FORMALLY ESCC, QML OR JAN QUALIFIED ARE DEEMED SUITABLE FOR USE IN AEROSPACE BY THE CORRESPONDING GOVERNMENTAL AGENCY.

Resale of Ai-Thinker products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by Ai-Thinker for the Ai-Thinker product or service described herein and shall not create or extend in any manner whatsoever, any liability of Ai-Thinker.

Ai-Thinker and the Ai-Thinker logo are trademarks or registered trademarks of Ai-Thinker in various countries.

Information in this document supersedes and replaces all information previously supplied.

The Ai-Thinker logo is a registered trademark of Ai-Thinker. All other names are the property of their respective owners.

© 2015 Ai-Thinker - All rights reserved

<http://www.Ai-Thinker.com>